#### 1. Install mpich-4.0

./configure --prefix /home/users/ckshita/mpich-3.4.2/mpich-install/ --with-device=ch4:ucx

Configure, make, install

(There are other installation instructions inside the readme file of mpich.)

#### 2. Add mpich library to path

(Add gdal and mpich to path)

export

LD\_LIBRARY\_PATH="{your\_mpich\_install\_path}/lib":\$LD\_LIBRARY\_PATH

#### 3. Create new conda environment with python 2.7

Command: conda create -n new\_environment python=2.7

#### 4. Activate the environment

Command: conda activate new\_environment

#### 5. Install GDAL-2.2.2

- There is a readme file inside gdal-2.2.2/swig/python. You can read this file for installation instructions.
- Change Path to: gdal-2.2.2/swig/python
- Build:
  - o Command: python setup.py build
- Install:
  - Command: python setup.py install
- Check installation: which gdalinfo
- Change the path to the project folder path again.
- Add to path:

 Command: export LD\_LIBRARY\_PATH={your\_gdal\_path}/lib":\$LD\_LIBRARY\_PATH

## 6. Install mpi4py==3.0.3

(In desktop, both manual installation and pip installation work.)

Command: pip install mpi4py==3.0.3

### 7. Install requirements.txt

Command: pip install -r requirements.txt

### 8. Install anuga== 2.0

Command: pip install anuga==2.0.0

#### 9. Install Crest

- Change path to: cresthh/crest
- Install:
- o Command: python setup.py install

## 10. Install pypar

- Change path to: pypar\_2.1.4\_94/source
- Install:
- Command: python compile\_pypar\_locally.py
- o Command: python setup.py install
- Did not add python path in my PC. But had to add pythonpath for pypar Install pcre=8.45
- Might have to install pcre=8.45 using conda
  - o Command: conda install pcre=8.45

## 11. Run model\_runs.py

Command: mpirun -n 2 python model\_runs.py

# 12. Changing order of importing packages:

Sometimes, you might have to chagne the order of importing pypar and mpi4py.